





2225mm<sup>2</sup>  
 0.79mm gap  
 27.7pF  
 -39pF/mm

**SENSOR PLATES**




For std. loop configuration with JP5-1 wired to JP5-2  
 Wire J3-1,2,3,4 to J2-1,2,3,4 and J4-1 to +UP  
 For old loop configuration, with JP5-2 wired to JP5-3  
 Wire J3-1,2,3,4 to J2-1,2,4,3 and J4-1 to -UP



**FEEDBACK ACTUATOR**



	<b>FORCE BALANCE SEISMOMETER</b>	
	<b>YUMA SENSOR &amp; ACTUATOR</b>	
DF NELSON	REV 4.0	
	10-16-2014	